

INSTRUMENT PANEL

Article Text

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM

ARTICLE BEGINNING

1990-92 SAFETY EQUIPMENT

Instrument Panels

1990-92 Passat

1991-92 Cabriolet, Corrado, Fox, Golf,

GTI, Jetta, Vanagon

DESCRIPTION & OPERATION

Instrument cluster for most models includes speedometer, fuel gauge and temperature gauge. Optional instruments include clock, tachometer, voltmeter and oil temperature gauge. See Fig. 3.

Printed circuit provides voltage to gauges. A voltage regulator attached to printed circuit controls voltage to fuel and temperature gauges. Most warning lights are a Light Emitting Diode (LED). To replace diode, pull from printed circuit socket.

TESTING

NOTE: Volkswagen Tester (VW 1301) is required for resistance tests. Tester settings are numerical. Settings do not indicate resistance in ohms. Manufacturer does not supply resistance values in ohms.

VOLTAGE REGULATOR TEST



1) If only one gauge is inoperative, regulator is not defective. If both fuel and temperature gauges are inoperative, voltage regulator may be faulty or have a bad ground connection.

2) Partially remove instrument cluster. Position cluster so regulator can be reached with voltmeter probes. Leave chassis harness connected. Ensure ground connection at regulator is tight.

3) On all except Cabriolet, turn ignition on. Connect voltmeter negative(-) lead to terminal No. 2 of regulator. Connect positive () lead to terminal No 1. See Figs. 1 and 2. Meter reading should be 9.5-10.5 volts. If reading exceeds specification, replace voltage regulator.

4) For Cabriolet, turn ignition on. Connect voltmeter negative (-) lead to terminal No. 2 of regulator. Connect positive lead (+) to terminal No 3. See Figs. 1 and 2. Meter reading should be 9.5-10.5 volts. If reading exceeds specification, replace voltage regulator.

Saturday, March 18, 2000 09:17PM

[illegible]

INSTRUMENT PANEL
Article Text (p. 3)
1991 Volkswagen Vanagon
For Volkswagen Technical Site
Copyright © 1998 Mitchell Repair Information Company, LLC
Saturday, March 18, 2000 09:17PM

| Application | Dial Setting | Indicator |
|--|--------------|-----------|
| Cabriolet & Fox | 55 | Full |
| | 560 | Empty |
| Corrado & Passat | 50 | Full |
| | 160 | Half |
| | 350 | Empty |
| Golf, GTI & Jetta | 52 | Full |
| | 550 | Empty |
| Vanagon | 50 | Full |
| | 320 | Empty |
| AA | | |

| TEMPERATURE GAUGE TESTING | | |
|--|--------------|-----------|
| AA | | |
| Application | Dial Setting | Indicator |
| Cabriolet & Fox | 500 | Cold |
| | 62 | Hot |
| Corrado & Passat | 80 | Normal |
| | 50 | Hot |
| Golf, GTI, Jetta & Vanagon | 510 | Cold |
| | 50 | Hot |
| AA | | |

WIPER/WASHERS

For testing information on wipers, see WIPER/WASHER SYSTEMS article in SAFETY EQUIPMENT.

REMOVAL & INSTALLATION

INSTRUMENT CLUSTER (CABRIOLET)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

- 1) Disconnect battery ground cable. Disable air bag. Remove steering wheel.
- 2) Tilt shelf downward, remove mounting screws and remove shelf. Remove instrument panel cover screws and mounting clips. Remove

INSTRUMENT PANEL

Article Text (p. 4)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM

instrument panel cover. Remove instrument panel insert trim screws and pull off instrument panel insert trim.

3) Remove instrument panel insert screw and tip instrument panel insert forward. Press speedometer cable lugs together and disconnect speedometer cable from instrument panel insert.

4) Disconnect multi-point connector, and remove instrument panel insert. To install, reverse removal procedure.

INSTRUMENT CLUSTER (CORRADO)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

1) Disconnect battery ground cable. Remove steering wheel only when removing complete instrument cluster housing. Remove trim screw caps and screws located on lower part of instrument cluster trim. Remove instrument cluster trim.

2) Remove trip odometer reset button. Remove trim cover retaining screws. Remove trim cover from instrument cluster. Remove instrument cluster housing retaining screws. Pull instrument cluster from dash panel. Disconnect multi-point connector, MFI vacuum hose (if equipped) and speedometer drive cable. Remove instrument cluster housing.

NOTE: All components in instrument cluster, except for printed circuit, can be removed from front, without removing complete instrument cluster housing.

3) Disconnect speedometer cable, remove mounting screws and pull speedometer from housing. Squeeze locating pins on other instruments and pull from housing. To install, reverse removal procedure.

INSTRUMENT CLUSTER (FOX)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

INSTRUMENT PANEL

Article Text (p. 5)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

1) Disconnect battery ground cable. Remove steering wheel. Carefully remove covers from vacant switch positions. Depress switch spring retainer and remove switches from instrument panel. Mark for reassembly and disconnect wire connectors from switches.

2) Remove 4 instrument cluster trim retaining screws. Remove instrument cluster trim panel. Remove 2 instrument cluster retaining screws. Remove speedometer cable. Disconnect cluster wire connector and remove instrument cluster. To install, reverse removal procedure.

INSTRUMENT CLUSTER (GOLF, GTI & JETTA)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

1) Disconnect battery ground cable. Remove steering wheel. Remove lower instrument panel retaining screws, and lower on left side. Remove remaining retaining screws, and lower instrument panel tray on right side.

2) Remove gearshift lever knob and boot. Remove retaining screw(s) and slide console rearward. Separate all electrical connections and lift out console.

3) Pull off all temperature control knobs/levers. Unclip trim plate and remove. Remove radio (or tray). Remove switches from instrument panel trim plate. Remove all retaining screws and remove instrument panel trim plate.

4) Remove instrument cluster retaining screws. Squeeze clips and remove speedometer cable from instrument cluster. Disconnect all vacuum hose connections and separate all electrical connectors. Remove instrument cluster. To install, reverse removal procedure.

INSTRUMENT CLUSTER (PASSAT)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system

INSTRUMENT PANEL

Article Text (p. 6)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM

operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

1) Remove battery ground cable. Remove instrument cluster trim. Remove instrument cluster trim cover. For tachometer and combination gauge, carefully pull gauge from housing and connector. For mechanical speedometer, remove mounting screws and carefully pull speedometer from housing.

2) To install, reverse removal procedure. Carefully guide plugs on rear of instruments into connector on printed circuit board.

CAUTION: DO NOT damage printed circuit when installing instruments.

INSTRUMENT CLUSTER (VANAGON)

CAUTION: To disable air bag system, disconnect negative battery cable and wait 20 minutes before working on vehicle. To activate system, reconnect negative battery cable. Perform a system operational check to ensure proper system operation. See SYSTEM OPERATION CHECK in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

WARNING: Failure to follow air bag service precautions may result in air bag deployment and personal injury. See SERVICE PRECAUTIONS in AIR BAG RESTRAINT SYSTEM article in SAFETY EQUIPMENT.

Removal & Installation

Disconnect battery ground cable. Reach behind cluster hood and pull back of hood upward. Pull hazard switch forward. Pull brake warning light housing toward front of vehicle. Remove 4 mounting screws and remove cluster. To install, reverse removal procedure.

INSTRUMENT PANEL


Article Text (p. 7)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM



- | | |
|-----------------------------|---|
| 1. Instrument Cluster | 12. Warning LED |
| Light Bulb | 13. Wire Terminal Housing |
| 2. Wire Terminal Housing | 14. Upshift Indicator (If Equipped) |
| 3. Trim | 15. Oil Pressure Warning |
| 4. Voltage Regulator | System Control Unit |
| 5. Speedometer | 16. Coolant Temperature Gauge |
| 6. Flexible Printed Circuit | 17. Instrument Cluster Insert |
| 7. Fuel Gauge | 18. Support Plate For Gauges |
| 8. Tachometer | 19. Digital Clock |
| 9. LED Holder | 20. Instrument Cluster Housing Cover |
| 10. LED Indicator Light | 21. Parking Brake/Brake Fluid Level |
| 11. Voltage Regulator | Warning Light Printed Circuit |
| Heat Shield | 22. Upshift Indicator LED (If Equipped) |

Fig. 3: Exploded View of Instrument Cluster (Fox Shown/Others Similar)

Courtesy of Volkswagen United States, Inc.

PRINTED CIRCUIT CONNECTORS

INSTRUMENT PANEL

Article Text (p. 8)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM




Fig. 4: Identifying Printed Circuit Connector (6 Pin)
Courtesy of Volkswagen United States, Inc.

INSTRUMENT PANEL


Article Text (p. 9)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM



CABRIOLET & FOX

1. Instrument Lights
2. Ground
3. Fuel Gauge (To Sender)
4. Coolant Gauge (To Sender)
5. Tachometer (Terminal 1)
6. Clock
7. High Beam
8. (Not Used)
9. Oil Pressure Warning System
10. O₂ Sensor System (If Equipped)
11. Oil Pressure Indicator (LED)
12. Alternator Warning Light
13. Turn Signal Indicator
14. Battery Voltage (Terminal 15)

VAN

1. Instrument Illumination
2. High Beam Warning (Terminal 56a)
3. Ground (Terminal 31)
4. (Not Used)
5. Clock
6. Coolant Temperature Gauge (To Sender)
7. Fuel Gauge (To Sender)
8. Battery Voltage (Terminal 15)
9. Tachometer (Terminal 1/w)
10. Turn Signal Flasher (Terminal 49a)
11. Alternator Warning (Terminal 61)
12. (Not Used)
13. Oil Pressure Warning
14. O₂ Indicator Light (If Equipped)

Fig. 5: Identifying Printed Circuit Connector (14 Pin)
Courtesy of Volkswagen United States, Inc.

INSTRUMENT PANEL


Article Text (p. 10)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM



1. Outside Temperature Sensor Ground (If Equipped)
2. To Coolant Low Level Sensor
3. Ground (Terminal 31)
4. Multifunction Indicator Memory Reset Switch (If Equipped)
5. Ground (Terminal 31)
6. Multifunction Indicator Memory Reset Switch (If Equipped)
7. Hall Speed Sensor Signal
8. From Oil Pressure Switch (High Side)
9. From Oil Pressure Switch (Low Side)
10. Tachometer Input Signal (Terminal 1/W)
11. Battery Voltage (Terminal 30)
12. Battery Voltage For Instrument Lighting (Terminal 58b)
13. Battery Voltage (Terminal 15)
14. (Not Used)
15. To MFI Mode Switch (If Equipped)
16. Alternator Warning Light (Terminal 61)
17. From Oil Temperature Sensor (If Equipped)
18. To Seat Belt Warning Light/Brake Warning Light (If Equipped)
19. Outside Temperature Sensor Signal (If Equipped)
20. Glow Plug (Diesel Only)
21. Fuel Gauge
22. Left Turn Signal
23. Coolant Temperature Sensor
24. Right Turn Signal
25. High Beam Indicator
26. (Not Used)
27. Signal From Speedometer Sensor (If Equipped)
28. A/T Selector Display (If Equipped)

92I01635

Fig. 6: Identifying Printed Circuit Connector (28 Pin)
Courtesy of Volkswagen United States, Inc.

INSTRUMENT PANEL

Article Text (p. 11)

1991 Volkswagen Vanagon

For Volkswagen Technical Site

Copyright © 1998 Mitchell Repair Information Company, LLC

Saturday, March 18, 2000 09:17PM

WIRING DIAGRAMS

See appropriate chassis wiring diagram in WIRING DIAGRAMS.

END OF ARTICLE